



Supine Stander

Standing changes how people see and experience the world. Our Supine Standers allow for greater social interaction and involvement in a wide range of therapeutic or recreational activities. With posterior and lateral support, the Supine Stander provides maximum stability while allowing partial weight-bearing and freedom of movement.

Why use a Supine Stander?

- **Standing option for medically involved clients:** The firm main board of the Supine Stander gives users with significant musculoskeletal weakness secondary to prolonged immobilization the opportunity to be positioned upright. Stability is provided posteriorly, making the Supine Stander a comfortable option for users with tracheotomy.
- **For gradual progression to an upright position:** The Supine Stander is effective for assisting individuals who have been bedridden for a long time to a standing position. The precise angle adjustment makes it ideal for people with orthostatic hypotension to lessen the adverse hemodynamic response from a rapid change in position.
- **Upright interaction:** Users can be at eye-level with their peers, participating in activities and initiating communication.
- **To improve head control:** The head support on the stander can be flipped down to allow the user opportunities to initiate and maintain head control.
- **Easier transfers:** The large Supine Stander's main board can be lowered to 21" off the ground when in the horizontal position, making transfers easier from a wheelchair or bed.



Find letters of medical necessity and studies on the therapeutic benefits of standing at: www.rifton.com/supinestander

adjustable and stable, the Supine Stander is ideal for the classroom. The vertical height adjustment makes transfers easier and provides versatility, adapting to the needs of many different students. And in the stander they're more alert and active.

Larry Ezzard, CRTS
Past President of Mobility Designs
Atlanta, GA

Supine Stander features







Supported by the hand Anchor, this child is able to participate in activities she enjoys.




This client has advanced so far that the headrest can now be flipped back out of the way.



The Supine Stander stays secure at any angle. Turn the crank to gradually increase weight-bearing.

Easy transfers for large clients



The large Supine Stander makes transfers easy. The manual crank raises the stander from 21" (wheelchair height) to 30" in the horizontal position.



Use the frame's marked calibrations to record and maintain each client's optimal position.



Once upright, the client is on the same level with caregivers and peers and can interact with her environment.



Components



Tray

The tray has a smooth, cleanable surface with rounded corners. Adjust the armrests to change the angle of the tray.

Inside dimensions: 26"x15"





Additional laterals

Add a pair of large or small additional laterals for extra support.





Sandals and wedges

Sandals and wedges raise heels or toes. Configure them with the unique "stack and latch" feature. For asymmetrical leg lengths, combine two wedges under one sandal.

Small: 3"x7", **med:** 4"x9", **large:** 5"x101/2"





Adjustable abduction wedge

The adjustable abduction wedge can be changed from 3½" to 11" in width depending on how much abduction is desired.





Round abductor

The round abductor helps maintain 4" of comfortable knee separation.



Components (continued)



Collar

The collar adds 2" of separation to the round abductor.

(Requires round abductor)





Hand Anchor

The hand Anchor attaches to the tray with a powerful suction cup. With a secure anchor point for one arm, the user can perform tasks more easily with the other arm and hand.







2022 order form

Use dimension chart to select appropriate size.

User di	mensions (inches)	E420 small	E430 large			
Height		30-50	46-72			
	Key user dimension: height Select the appropriate stander by the user's overall height. Choose the model that allows for growth.					
I	Important: User's weight must not exceed the maximum working load.					

Item dimensions (inches)	E420 small	E430 large	
Board length and width	53 x 16½	73 x 19	
Distance between laterals	7-13	9-16	
Height when horizontal	281/2	21-30	
Height when vertical	541/2	74	
Base length and width	37½ x 27	46½ x 29½	
Max. working load (lb)	100	250	



			E420 small		E430 large		
* Supine Stander includes padding, footboard, chest strap, leg straps, one pair of laterals, one pair double-locking casters.			E40	\$2,980	E41	\$4,670	
Additional laterals (pair)		Small	E504	\$152	N/A		
		CHOOSE	Large	N/A	••••	E439	\$225 🗌
Tray			E404	\$300 🗌	E414	\$370	
Adjustable abduction wedge				E945	\$245 🗌	E945	\$245 🗌
OSE	Round abductor				\$105 🗌	E933	\$105
Collar				E934	\$84 🗌	E934	\$84
Sandals (pair)			Small	E422	\$95 🗌	N/A	
		СНООЅЕ	Medium	E433	\$105	E433	\$105 🗌
		m	Large	N/A		E432	\$105 🗌
Wedges (pair, require sandals)		Small	E424	\$68	N/A		
		СНООЅЕ	Medium	E435	\$74 🗌	E435	\$74 🗌
		m	Large	N/A		E434	\$79 🗌
Hand Anchor			K821	\$158	K821	\$158 🗌	
Total			E420	\$	E430	\$	

^{*} Required