

USER MANUAL

MJ-MAGNET CLASP BELT



It is important to read this manual before installation and use of MJ-Magnet Clasp belt as well as the advice given on the safety and use followed to ensure the optimal utilization of the MJ-Magnet Clasp belt.

MJ-Magnet Clasp belt is designed for use in the positioning of PWD that causes uncontrolled movements, or for active persons who run the risk of leaving the seat in a vehicle, -the standard safety belt which may cause a risk of falling or ejection during transport.

- The MJ-Magnet Clap belt is designed and tested in accordance with DS/EN ISO 10525:2007 Personnel lifting for disabled persons – Requirements for test methods.
- The test is performed as a static test, the specified person weight for use is 110 kg.

MJ-Magnet Clasp belt is used in connection with a seat with backrest which is attached to the vehicle.

MJ-Magnet Clasp belt designed for use by children and adult.

MJ-Magnet Clasp belt is NOT a safety belt, but a positioning belt to ensure the person proper location on the seat.

MJ-Magnet Clasp be used for any purpose other than described, the CE marking and warranty are only valid to the manufacturer's written approval.

Table of Contents

1. CE Declaration of Conformity.
2. The use
3. Use with harness pillow, harness with backrest and safety seat.
4. Maintenance.
5. Warranty

2. Anvendelse:




Place the belt chest cushion against the seat backrest, put shoulder belts with triangular assembly plate of the seat backrest. Plug the triangular assembly plate with the two lower belts and crotch belt in between the seat and backrest.



Place the triangular assembly plate high on the back of the backrest, close the lock and tighten the belt. This is done by tightening the belt on the triangular assembly plate.



Open magnetic clasp on the belt chest pad and crotch strap assembly.



Place the person in front on top of crotch belt. Set crotch belt loosely around the person.



Close magnet clasp belt around the person thereby ensuring the person in the seat with chest pad and crotch belt. Make sure the chest pad is positioned so it does not touch the neck. Then adjust the crotch on the back of the backrest in the lower triangular collection plate, the crotch belt should not be tight.

USER MANUAL

MJ-MAGNET CLASP BELT



Attach magnets on top of locking pin, you can hear a little "click", when the magnet is brought into place. Subsequently, the magnet Clasp belt is secured.

Removing magnet lock is done by passing the red removal tool down on the magnet, the magnet unlock and you can remove the magnet and the tool from the locking pin.

(Magnet lock and removal tool)



The person is now fixed in the seat.

Make sure the belt is closed and adjusted.

1 Set the crotch belt so that the crotch is tight. The setting is made on the back of the backrest and allowed it to be, so there may be a flat hand under belt.

2 Chest pad should not be placed on the person's neck.

Safety:

When the person is placed and fixed by MJ-Magnet clasp belt put on the vehicle's seat belt around the person, in accordance with regulations for the transport of children and adult.

Never leave children or adult unattended, when they are fixed with MJ-Magnet clasp belt



3. Use with harness pillow, harness pillow with backrest and safety seat.



The seat cushion is placed on the vehicle seat
The MJ-Magnet clasp belt is placed around the vehicle seat and under the vehicle seat belt, as shown in section 2.



The seat cushion with backrest is placed on the vehicle seat
The MJ-Magnet clasp belt is placed around the vehicle seat, under the vehicle's seat belt, as shown in section 2.



The child seat is placed and fixed as described in its instruction manual, this can be accomplished by the use of the vehicle's safety belt or Isofix fitting.
The MJ-Magnet clasp belt is placed under the car seat's approved seat belt and fastened around the car seat and backrest.

4. Maintenance.

MJ-Magnet clasp belt is made of polyamide and have a breast pad made of soft, breathable 90% cotton and 10% viscose fabric

MJ-Magnet clasp belt can be washed at 40°C, do not use tumble dryer for drying after wash.

Daily maintenance before use, inspect MJ-Magnet clasp belt for damage and wear, also check the locks functions.

MJ-Magnet clasp belt must be send for repair, if there are any damage or wear.

Disposal.

When MJ-Magnet clasp belt should no longer be used, this can be sent for destruction of recyclable ferrous waste and combustibile material.

5. Warranty.

The manufacturer's warranty covers manufacturing, materials and function of the equipment supplied. The warranty is applicable when the equipment is operated in accordance with instructions for use and for the purpose for which the equipment is delivered.

The warranty covers repair of defects in the equipment supplied, and not possible effects caused by these.

All repairs and replacement of components during the warranty period shall not be made without prior consent and approval of the manufacturer.

The warranty period is 2 year calculated from delivery data.